


LITEMALADSP

# Product manual


—MLite-880

Version: v2.1.0


Release date: July 10, 2025



# Functions and Operating Components Introduction



1	Speaker	5W	9	Key board	
2	Power LED	Blue	10	TUNING	Encoder with switch
3	Ext Antenna	AUX to SMA	11	EARPHONES	Stereo Out
4	Charging LED	Green/Red	12	TypeC	Externalpower supplycharging inputData interface
5	Bluetooth LED	Blue			
6	ON-OFF	Power Switch	13	BATTERY COMPARTMENT	
7	TF	MICRO SD (16G)	14	Antenna	Rod Antenna
8	LCD	DOTS192X64	15	Support frame	



### Power supply:

MLite-880 is powered by a 21700 3.7V rechargeable lithium battery.

Place a 21700 lithium battery in the correct polarity direction in the battery compartment.


You can also use a power adapter (5V1A) connect to the Type C

Charging-LED flashes red during charging, Charging-LED flashes green after charging is completed

















Attention: This device is not suitable for fast charging

# WALAHITTEAM

Display function indicator



bandwidth  
spectrum


Indicator	Description	Operate	Indicator	Description	Operate
	S Meter	[5]-[A]-[1]		AM mode	[2]-[5]
	Audio output	[A]		SAN mode	[2]-[6]
	SQL trun on	[B]		NFM mode	[2]-[7]
	NR trun on	[C]		WFM mode	[2]-[8]
	USB mode	[2]-[1]		Volume:	[Knob]
	LSB mode	[2]-[2]		RDS	[5]-[5]
	CW mode	[2]-[3]		Time	
	DSB mode	[2]-[4]		Battery	

# Operating nstructions


The operation of MLite-880 is based on the combination of keyboard and knob

TUNING

Encoder with  
switch




Key board



## KeyBoard Introduction

Key	Description	Key	Description
[Knob KEY]	Volume / Frequency	[5]	Display Settings /option 5
[A]	Audio output channel selection	[6]	Audio Settings
[B]	SQL enablement	[7]	Recording Menu
[C]	NR enablement	[8]	Channel Record
[D]	Return	[9]	Null
[1]	Frequency Step Menu/Option 1	[0]	Bands
[2]	Modulation mode menu/Option 2	[*]	Multi functional keys
[3]	Device Menu /Option 3	[#]	Enter
[4]	Manually enter frequency/option 4		

## Keyboard button [1] - Frequency Step Selection menu




Frequency Step: Used to adjust the encoder step size

Press key [1] - [9] to select the applicable option, Press key [D] to Exit menu

---

## Keyboard button [2] - Modulation Mode Selection menu



**Mode menu:** Used to set the receiving mode

Press key [1] - [9] to Select the desired demodulation mode

\* WFM is only available within the frequency range of 65-108MHz

Press key [D] to Exit menu

---

### Keyboard button [3] - Device Menu

Press key [A] / [B] to change interfaces (2 pages)

Press key [1] - [5] to select configuration item

Press key [D] to Exit menu

```
RADIO SETTINGS 1/2 A: NEXT B: PREV
1: Antenna type for SW: 50 Ohm
2: Blast disable
3: Attenuator for SW: disabled
4: WFM bandwidth: Auto
5: Pres. correct: 10 30 100m
```

- [1] Select input antenna impedance for SW: 50 Ohm / Hiz

\* <50 Ohm> for using an external antenna

< HiZ > for using telescopic rod antenna

- [2] Turn on/off the power LED: disable / enable
- [3] High frequency attenuator (ATT) : disabled / 6 -36
  - \* Rotate [knob] to adjust the ATT value(db)
- [4] WFM bandwidth adjustment
  - \* Only valid in FM mode
  - \* Rotate [knob] to adjust the bandwidth value(56kHz-311kHz)
- [5] Frequency offset correction
  - \* Rotate [knob] to adjust the frequency offset (+-0.1ppm)

```
RADIO SETTINGS 2/2 A: NEXT B: PREV
1 WFM tuner mode: manual
2 FM tuner mode: scanning
3 Date and time settings
4 Bluetooth mode: disabled
5 About
```

- [1] WFM channel search mode: manual / scanning
  - \* IN scanning mode, return to the main interface.
  - Rotate [knob] forward or backward to search for channels up or down

- [2] AM channel search mode: manual / scanning
  - \* IN scanning mode, return to the main interface.  
Rotate [knob] forward or backward to search for channels up or down
- [3] Date and time settings
  - \* 1. Time setting <HH: MM> Enter the time by pressing the keyboard digits  
Press key [A] to save, Press key [D] to return.
  - \* 2. Date setting <DD: MM: YYYY> -Enter the time by pressing the keyboard digits  
Press key [A] to save, Press key [D] to return.
- [4] Bluetooth function: disable / enable
  - \* Enable the bluetooth, MLite-880 will searching bluetooth peripherals automatically.  
Enable broadcast mode of your Bluetooth peripheral.  
MLite-880 will automatically connect to the target device after it is be found.  
Bluetooth LED will turn on when successful connection.
  - \* Restart Bluetooth When replacing other Bluetooth peripherals.
- [5] Device info: Software version and device ID

## Keyboard button [4] - Manually Input Frequency

ENTER FREQUENCY

10.00

Incorrect frequency

\* - dot, A - kHz, B - MHz, C - Clear  
D - exit, # - Enter

Input Frequency by pressing the keyboard buttons

- [1] - [9] input numbers
- [A] end of "kHz" units
- [B] end of "MHz" units
- [#] Confirm input
- [C] Cancel input
- [D] Exit menu

\* EXA: Target frequency 10.00MHz, you may input [1], [0], [\*], [0], [0], [B].

---


## Keyboard button [5] - Display Settings

Press key [A] / [B] to change interfaces (2 pages)

Press key [1] - [5] to select configuration item

Press key [D] to Exit menu

# VISUAL SET. 1/2 A: NEXT B: PREV



- [1] LCD brightness level: maximal / middle / minimal
  - \* Rotate [knob] to adjust the brightness level
- [2] LCD brightness off time: disable / 5 S - 300S
  - \* Rotate [knob] to set the brightness off time
- [3] Average value of frequency spectrum curve : 50 - 99
  - \* Rotate [knob] to set the value
  - \* The higher the value, the smoother the appearance of the frequency spectrum curve
- [4] frequency spectrum curve fill: disable / enable equenc
  - \* Display spectra in line or color form
- [5] RDS view: disable / enable
  - \* Display RDS information on the screen in FM mode: PI: XXXX

VISUAL SET. 2/2 A: NEXT B: PREV

[1] S meter view: disable

- [1] S meter view: disable / enable

\* Display Signal strength on the screen

\* Invalid in FM mode

---

## Keyboard button [6] - Audio Settings

Press key [A] / [B] to change interfaces (3 pages)

Press key [1] - [5] to select configuration item

Press key [D] to Exit menu

AUDIO SETTINGS 1/3 A: NEXT B: PREV

[1] Fil type: Narrow  
[2] Fil low freq: 0.00kHz  
[3] Fil high freq: 12.00kHz  
[4] NR level: 17  
[5] WFM skopov: disable

- [1] Filter type: Narrow / Normal / Wide
  - \* Rotate [knob] to set the wave filter type
  - \* Default threshold for narrowband: 0.00Hz - 8.00Hz
  - \* Default threshold for normalband: 0.00Hz - 12.00Hz
  - \* Default threshold for wideband: 0.00Hz - 15.00Hz
  - \* The threshold can be manually adjusted and save it in the corresponding type
- [2] Low threshold setting:
  - \* Rotate [knob] to set the frequency(Auto save)
- [3] High threshold setting:
  - \* Rotate [knob] to set the frequency(Auto save)
- [4] NR level 0 - 30


- \* Rotate [knob] to set the NR threshold
  - \* Only effective when NR enabled (Black to main interface, press key [C])
  - \* Invalid in FM mode
- [5] WFM stereo: disable / enable
- \* Use external headphones/speakers through audio port or Bluetooth



```
AUDIO SETTINGS 2/3 A: NEXT B: PREV
1 AGC mode: MANUAL
2 Manual gain: 20 db
```

- [1] AGC mode: MANUAL/FAST/MIDDLE/SLOW/LONG
- [2] AGC limit: 40 - 90(db)
- [3] AGC gain: 0 - 60(db)
- \*Rotate[knob] to set the AGC mode and AGC threshold(db)

# AUDIO SETTINGS 3/3 A: NEXT B: PREV



- [1] NB mode: NB dsiable / 1 / 2
  - \* pulse suppression mode, Noise blanker
  - \* Rotate [knob] to set the NB mode
- [2] NB threshold : 2.1 - 20.0
  - \* threshold of activation of the pulse suppressor
  - \* Rotate [knob] to set the NB threshold
- [3] Equalizer type: VOICE / POP/ JAZZ /BASS / ROCK / CLUB / LIVE / SOFT / EQ OFF
  - \* the selected type of equalizer.
  - \* Rotate [knob] to select
- [4] Key beep level: key beep off / 1 - 20
  - \* the level of “beep” when pressing key

- \* Rotate [knob] to adjust the value
- [5] SQL threshold: -30 dBm --120 dBm
  - \* the threshold for triggering the SQL noise suppressor
  - \* Rotate [knob] to set SQL

---

## Keyboard button [7] - Recording Menu



Firstly, set the channel to be recorded on the main interface and press the keyboard button [7] to enter the recording menu.

- [1] START

- \* Rotate [knob] to adjust the audio gain level when recording
- \* The recording indicator should be approximately at the level of half to  $\frac{3}{4}$  of the scale

- [2] STOP



press key [A] / [B] to Switch page, Rotate [knob] to Browsing List

press key [D] to Exit menu

\* Hover the cursor at position" CREATE NEW CELL "and press [\*] to save the current channel and create it in the list. There are 10 pages, 50/page, a total of 500 channels can be saved

\* Rotate [knob] to select the saved channel, press [\*] to enter the editing page.

## EDIT MEMORY CELL

01. mem1 7.50MHz LSB

[2] Edit name      [3] Delete cell  
[0] Exit this menu

- [2] Edit name Rename
- [3] delete cell Delete Channel
- [5] Exit Return

# EDIT MEMORY CELL

Mem1



- [A] Next -[B] Prev

- [\*] Restore text --Cancel input

- [D] Return to previous menu --Save changes and return

\* Move the cursor using the [A] [B] buttons and Rotate [knob] to select text / numbers / symbols.(limit 7 characters)

---

## Keyboard button [0] - Bands

press key [A] / [B] Switch options page (1, Broadcast / 2, Amateur / 3, FM & VHF bands)

\* Rotate [knob] to Select frequency band

press key [#] to enter and return to the main interface

press key [D] to Exit menu





FM&VHF bands

GEN: \*

FM&VHF bands

88MHz - 108MHz (FM)

108MHz - 136MHz (Airband)



### Firmware update :

You need to turn off the receiver first.

Press and hold the button [1] to turn on the radio, then release the button [1].

The screen will show a notification that the device is in DFU mode.

Connect the device data interface (TypeC) to the PC and update the software.